

KIWO SCRUB PAD & GRIPPER HANDLE

1. DESCRIPTION

KIWO replaceable Scrub Pads and reusable Gripper Handles are used for reclaiming screens after printing. After applying appropriate reclaiming chemical i.e. ink wash, stencil remover, haze remover, or degreaser, these scrub pads are used to distribute the chemicals and to reclaim screens quickly and easily. The scrub pads are made from 100% recycled material.

2. APPLICATION

To avoid cross contamination, dedicate one brush for one application. In other words, use one scrub pad for ink removal only, another scrub pad for emulsion removal only, and another scrub pad for haze removal only, etc.

INK REMOVAL

Use dedicated scrub pad together with an effective ink wash product like KIWOCLEAN CONCENTRATED INK WASH, KIWOCLEAN LM 781E, or EXCEL INK WASH to remove ink residue from the screens. Apply ink wash product to squeegee side of screen and work it around with the scrub pad to dissolve the ink residue. Repeat this process on the substrate side of the screen.

STENCIL REMOVAL

Use dedicated scrub pad together with an effective stencil remover/reclaimer like KIWO STENCIL REMOVER1:20 concentrate to remove the stencil from the mesh. Apply stencil remover to the substrate side of a wet screen and work it around with the scrub pad to break down the stencil. Repeat this process on the squeegee side of the screen.

HAZE REMOVAL

Use dedicated scrub pad together with an effective haze remover like KIWO's MEGA CLEAN ACTIVE, HAZE REMOVER, or FAST LIQUID HAZE REMOVER to remove ghost, haze from the mesh after removing the ink and stencil from the screen. Apply haze remover to the screen and work it around with the scrub pad to remove stains. Repeat this process on the opposite side of the screen.

DEGREASING

Use dedicated scrub pad together with an effective degreaser like KIWO's DEGREASER 1:20 concentrate, PREGAN A9, or ULTRA PREP to remove dirt, oil and other contaminants from the screen. Apply degreaser to the screen and work it around the entire screen on both sides with the scrub pad to clean the mesh.

3. PHYSICAL DATA

White Scrub Pad: 3.5" x 6" x 1"
Green Gripper Handle: 3" x 5½" x 2"

4. PERSONAL PROTECTION

During and after use with screen reclaiming products, brush can contain chemical residues.

It is recommended to wear protective glasses and gloves when ever handling screen reclaiming products. See Material Safety Data Sheet of each product used for additional information.

5. PACKAGING

Scrub pads and gripper handles are sold separately. Each is sold by the case with 24 per case.

6. ADDITIONAL INFORMATION

For additional product information, please visit our web site at www.kiwo.com. All products mentioned in this Technical Information are available through KIWO Inc. and its distributor network. For further information contact your authorized KIWO distributor or KIWO directly.

Thank you for choosing **KIWO**.