

KIWO SCREEN BRUSH #1, #2, #3, & #4

1. DESCRIPTION

KIWO SCREEN BRUSHES provide you with a specific brush for each application step in the stencil cleaning process. Each brush is resistant to chemicals and has an ergonomically shaped handle. The different colored bristles allow for safe and fast identification of the appropriate application.

2. APPLICATION

Use only the specific brush for the specified screen cleaning step. For example, only use the degreasing brush for degreasing. Using it for other steps in the cleaning process can contaminate the brush and result in unintended consequences.

KIWO SCREENBRUSH #1

Application Step: DEGREASING only
Brush Description: long white bristles

Use only for degreasing screens. Use KIWO SCREENBRUSH #1 together with KIWO DEGREASER 1:20 concentrate or PREGAN A9 to remove contamination/oils/chemical residue from cleaned screens.

KIWO SCREENBRUSH #2

Application Step: INK REMOVAL only
Brush Description: long blue bristles

Use only for pre- and intermediate ink cleaning of the screen prior to stencil removal. Use KIWO SCREENBRUSH #2 together with any of KIWO's ink wash cleaning chemicals like EXCEL INK WASH, KIWOCLEAN LM 781 E, or KIWOCLEAN CONCENTRATED INK WASH to remove ink residue from a screen.

KIWO SCREENBRUSH #3

Application Step: STENCIL REMOVAL only
Brush Description: long green bristles

Use only for decoating/stencil removal. Use KIWO SCREENBRUSH #3 together with any of KIWO's stencil removing chemicals like KIWO STENCIL REMOVER 1:20 concentrate to remove the stencil from the mesh.

KIWO SCREENBRUSH #4

Application Step: HAZE REMOVAL only
Brush Description: short red bristles

Use only for mesh post treatment/haze removal. Use KIWO SCREEN BRUSH #4 together with any of KIWO's haze removing chemicals like KIWO HAZE REMOVER, FAST LIQUID HAZE REMOVER, MEGA CLEAN ACTIVE, or PREGAN PASTE with KIWO ULTIMATE INK WASH, KIWO INK WASH, or PREGAN C4 to remove emulsion and ink haze/residue from a screen.

3. PHYSICAL DATA

Color:	#1	white
	#2	blue
	#3	green
	#4	red

4. PERSONAL PROTECTION

During and after use with screen reclaiming products, brush can contain chemical residues. Rinse brushes thoroughly after each use.

It is recommended to wear protective glasses and gloves when ever handling screen reclaiming products. See Material Safety Data Sheet of each product used for additional information.

5. PACKAGING

1 brush per box

6. ADDITIONAL INFORMATION

For additional product information, please visit our web site at www.kiwo.com. All products mentioned in this Technical Information are available through KIWO Inc. and its distributor network. For further information contact your authorized KIWO distributor or KIWO directly.

Thank you for choosing **KIWO**.